E07K is one kind of Portable Headphone Amplifier, which with high performance of USB Audio, DAC and Headphone Amplifier. It could FiiO° connect with PC, cell phones and other audio players so that you can enjoy high quality music.

ANDES

USB DAC Headphone Amplifier

User manual

Specification •Output power: $> 220 \text{mW}(32\Omega)$; $> 36 \text{mW}(300\Omega)$

Headphone Impedance Range: 16Ω~300Ω

Frequency Range: 20Hz~20KHz

Brief Introduction

Power supply: Internal rechargeable Li-ion battery

•Support sampling rate(USB decode): Max. 96KHz/24 Bit

•Size: 96mm×55mm×15.2mm

•Weight: 102g

List of items in the package (please verify) E07K USB cable

3.5mm audio cable 1pcs Dual laver soft pouch 1pcs Silicone band 2pcs Silicone case Rubber feet 6pcs Lens protective film 2pcs 1ncs User manual

Default setting

@BASS: 0 @ BALANCE: 0 @GAIN: 6dB @USB CHG: ON @SLEEP: OFF @DISPLAY: ON ®MAX VOL: 60
® VOL MEM: OFF

®RUNTIME: 00D 00H (hour)

indication for charging operation				
	indicator	Meaning	Charging	Battery full
	*	whether charging is working or not	USB CHG = ON display USB CHG = OFF disappear	USB CHG = ON display USB CHG = OF disappear
	Battery power sign	when displaying empty battery ,please charge timely	progress bar of battery power	fully charged who sign stopped flashing

Menu Instructions

①B: Bass T: Treble ②Status indication of input connectors ①

⑤Battery indicator

USB(default or USB) AUX(AUX/LINE IN) BOTOUSBOOF 5 DOCK (DOCK OUT) (3) Sleep Timer (minutes) VOL ZO 4 Charging switch indicator

Adjustable range:-10dB ~ 10dB; 2dB/step TREBLE TREBLE Adjustable range:-10dB ~ 10dB; BASS BASS Adjust the balance of L/R BALANCE BALANCE Sound channel USB charging On ON USBCHG (USB CHARGE) OFF USB charging Off OFF Sleep function off SLEEP ★ 10~90 Sleep function time (Minute) Display backlight on DISPLAY Set shut-off timer of display backlight, in second MENU MAX VOL Maximum volume limit. 20~60 (Max Volume Limi 20~60 Volume memory function OFF VOL MEM (Volume Memory) Volume memory function ON Fw Version Firmware version Time of system operations application, it will restart from Run Time zero after reset button is pressed, reloading default setting, or when the battery

★Sleep will be set "OFF" automatically, when E07K Power off each time.

Operation instructions Volume "+""-" 3.5MM headphone output jack - Main menu state, when operating .it would - Be able to insert two headphones increase or decrease the volume. meanwhile and use both at the same time Headphone Impedance: 16Ω~300Ω •Output power: > 220mW (32Ω); Select menu item -Entering menu, when operating ,it would choose the menu forward or backward RESET - When E07K needs to be reset, please use it. Menu button - Use a small and insulating stick and press after inserting. - Entering next menu after operation. - Please make sure the current item when OLED display screen setting the menu. - Indicate various working and setting information Power/Exit State, indicator Fii^O - Charging state: red light on (off after - Control turn on/off, short press to turn on. fully charged) long press of 3 seconds to turn off. - Working state : blue light on - Back or exit the current menu. - Charging while working: red and blue Default Setting Loading default factory setting light are on at the same time.

 $> 36 \text{mW} (300 \Omega)$

MODEL.:E07K

Operation instructions

 Slid downward is HOLD, locking the functions of other buttons and display screen turning on/off meanwhile.

HOLD: (Unlocking Lock-in

HOLD button

Battery

- Fully charged, needs 180 minutes (testing in the condition of charging via computer USB port) Note: In order to speed up charging time, we

- Total runtime after fully charged: about 24 hours (under laboratory environment, for reference only)

advise users to charge under power off.

USB connector

then output audio signal

Computer

- Charge

- Connect computer USB, decode and


LO BYPASS

- DOCK Line Out sound effect switch (only valid when connecting DOCK)

LO BYPASS: On: adjust the volume of E07K, setting of sound effect is ineffective. Off: adjust the volume of E07K, setting of


sound effect is effective

Line input connector - External audio signal input




DOCK connector

- Specialized dock for E09K



- Specialized dock for L7



Operation and instructions

E07K USB IN-- PC USB decoding and then headphone output power on (short press'power') connect E07K to computer

(use the matched USB cable) Adjust to suitable volume

(Recommend volume at 20 or below, or follow Procedure (3) to preset volume)

> connect headphone (To any of the 3.5mm Headphone output jack)

Start the audio application in PC

(Note: Any previously opened audio application might lose its sound after connecting E07K to PC, Please close then reopen the application.

refer to below picture Select FiiO USB DAC-E07K in the output device menu)*

FIGURE DACEDA Mac os: System preferences-Sound-Output select "FiiO USB DAC-E07K" 4 b Show All Sound Effects Output Input Select a device for sound output Built-in Internal Sneakers

Windows:

FIIO USB DAC-FORK

E07K AUX IN-- headphone amplifier output

power on (short press 'power'

Connect input audio source to bottom AUX connector

(use matched 3.5mm audio cable) Adjust to suitable volume

(Recommend volume at 20 or below, or follow Procedure (3) to preset volume)

connect headphone (To any of the 3.5mm Headphone output jack)

Operation and instructions

E07K SETTING --TREBLE, BASS, BALANCE, GAIN USB CHARGE, SLEEP, DISPLAY power on (short press 'powe') MENU

(short press) select menu use VOL'+'/'-'button)

Return/exit (short press 'power')

Important notices

- *Do not repair, disassemble the device by yourself, and do not put it in the place with water
- ★When long time no using the E07K, please charge it periodically in order to make sure the lifetime of the battery.
- ★To avoid damaging your hearing and audio stereo system. please adjust a proper volume when enjoying music Please turn down the volume before plugging in the
- headphone, do not use headphone for a long time. ★Please turn off when inserting or pulling out DOCK or E09K.

FAQS

- •E07K's battery perhaps needs to be recharged when it does
- not works normally. To save battery power, please set display time(20S-60S) in display setting menu.(After display setting, display screen will be turned off automatically)
- •When without sound output, or the sound with noise, please check audio output device and the music, if they are in good
- •It perhaps the connector of audio input and earphone out do not connect perfectly, please pull out and then plug in again
- Please use the original or suitable audio connected cable. and make sure it can output normally.
- Factory setting ,to avoid mistakenly turning on/off, please set HOLD = Lock-in in factory setting.
- •If can not be sucessfully powered on, please check whether HOLD key is locked, and set HOLD to be UNLOCKED.

DATE: FC (E Manufactured by FiiO Made in China 5190122

Warranty provision

Amplifier: one year free maintenance.

② Accessories: No warranty.

Qualified Certificate

FiiO Warranty for reference only, please subject to the provisions of the local Sales Agents.

Specially stated

- * FiiO has the final interpretation of these instructions. If any discrepancy is found between the instruction manual and the product, please refer to the actual product. ★FiiO reserves the right to amend the technical
- specifications without prior notice.
- *FiiO reserves the right to amend these instructions without prior notice.
- *Manufacturer reserves the right to amend technical specifications without prior notice.

Contact

FiiO Electronic Technology Ltd. Address: 2/F, F Building, Hougang Industrial Zone, Shigang Village, Huangshi West Road, Baiyun District, Guangzhou, China. Postcode: 510430 Web: http://www.fijo.com.cn facebook (http://www.facebook.com/fijochina)

If E07K is not working normally or any doubts.

twitter (https://twitter.com/FiiO official)

Please login it(http://fiio.com.cn/support/FeekBack.aspx) and post for advisory or send email to market@fiio.com.cn directly.